



5050 Kansas Ave. Kansas City, KS 66106 816-765-1444

Instructions – Food Warmer with Sterno

Start

- Begin by using four sternos in the hot box.
The four will heat the box to approximately 160° F,
depending whether the box is used indoors or outdoors.
- To increase the temperature, add more sterno.

Cleaning

- Throw away all debris and used sterno.

This document was created with Win2PDF available at <http://www.win2pdf.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.
This page will not be added after purchasing Win2PDF.