



5050 Kansas Ave. Kansas City, KS 66106 816-765-1444

Propane Tent Heater 170,000 BTU Instructions

WARNINGS: DO NOT use in an explosive atmosphere. Keep heater away from areas where flammable liquids or vapors are stored or used.

1. **TURN OFF** LP tank when the heater is not in use.
2. **DO NOT** alter unit in any manner or bypass safety valve.
3. **ALWAYS** place heater on a hard and level surface.
4. **DO NOT** use if wind velocity is greater than 10 mph because of flame-out possibility.
5. **Make sure Heater free from debris being sucked into the intake vent.**

Before Turning the Gas Supply "ON":

1. **INSPECT** hose assembly for excessive wear or cuts.
2. **CHECK** that surrounding area is free of combustible materials.

To Light:

1. Make sure heater has been plugged into an electrical outlet, if you have to use an extension cord, IT MUST BE GROUNDED. Ensure that the hose has been connected to the propane tank.
2. **Slowly**, turn valve (counter clockwise) on top of the propane tank until it is fully open. Do not open valve quickly as it may trip a safety mechanism in the heater that will turn off the unit. If this does occur, heater must be reset. (see # 5) If there are two propane tanks linked to a single heater, open the valves on both tanks.
3. Turn switch on side of heater to on (up) position. Down position is fan only.
4. Set the thermostat inside the tent to a desired temperature above 70°. The heater will turn off when desired temperature is reached and turn back on when temperature falls below the indicated level.
5. If heater does not go on, make sure electrical outlet is working and propane tank is open. Be sure to check that the thermostat has been set to a least 70°. If it is still not working, open doors on both ends of the heater and hit the red reset buttons.
6. On heaters that do not have doors on both ends, you will have to remove a grill to access reset buttons.
7. In case of snow, please turn on the heaters so that the snow on the top of the tent will melt.

To Shut off:

1. When heater is no longer needed, turn heater to the off position and close valve on the propane tank until is completely shut.

This document was created with Win2PDF available at <http://www.win2pdf.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.
This page will not be added after purchasing Win2PDF.